



TAMROTOR MARINE
COMPRESSORS



TAMRÖTOR MARINE
COMPRESSORS



1st DK (P)



TAMROTOR MARINE
COMPRESSORS

For spare parts, service and technical questions, please contact:

TAMROTOR MARINE COMPRESSORS AS

Tel.: +47 22 91 85 00

Fax: +47 22 91 84 93

24-hour service telephone: +47 99 21 70 20

E-mail: aftersales@tmc.no

www.tmc.no

Commissioning: Read the operation and maintenance instructions carefully.

Wrong direction of rotation may damage the compressor.

Important! Use the correct oil type in the compressors. For specifications of oil type, contact TMC by e-mail (aftersales@tmc.no) or fax (+47 22 91 84 93).

Changing intervals for oil and oil filters:

Ambient temperature	Compressor running temperature	Recommended oil	Control intervals, oil	Maximum change intervals
5-30°C	Max. 30°C	ISO VG 46 SYNT Synthetic	Daily	Every 1500 hours or once a year

Never different oil types must never be mixed!

Ensure sufficient cooling for the compressor.

Daily check points:

- Check oil level
- Check for leakage
- Check wiring
- Check running temperature
- Check water drain and adjustment

FOR SPARE PARTS AND SERVICE CONTACT
AFTERSALES@TMC.NO OR FAX (+47 22 91 84 93)